



MJRS3001/3001T



Rear Flip Seat for Yamaha® G14, G16, G19, and G22 Installation Instructions Addendum

What's in the box:

- 4 x Spacer
- 2 x M10 x 45 mm Bolt
- 2 x M8 x 45mm Bolt

NOTE: This addendum and the included hardware are designed to mitigate clearance issues with the seat frame and the bodywork and the footrest and the bumper. The installation of the included spacers is required for proper fit and will not degrade the structural integrity of this product in any way.

At **Step 13**, Use two spacers from this kit between the Seat Frame and the Rear Struts. Use the longer bolts supplied with this kit and the washers and nylock nuts from **Hardware Pack 3**.



At **Step 14**, use two spacers from this kit between the footrest and the bag well bracket. Use the longer bolts supplied with this kit and the washers and nuts from **Hardware Pack 3**.

